

VERSION	DATE	WHAT'S NEW
V0.1.8	December 24, 2020	<ul style="list-style-type: none"> Improved the maximum capacity estimation algorithm
V0.1.7	October 26, 2020	<ul style="list-style-type: none"> Changed the low temperature charging protection trigger point from -20°C to -25°C and recover point from -17°C to -20°C
V0.1.4	March 4, 2020	<ul style="list-style-type: none"> Improved the state of charge estimation algorithm Added the functionality of restarting the BMIC chip automatically if the sampling voltage is out of the valid range Resolved the issue where the host device would switch the slave device to shelf mode mistakenly after recovering from the under-voltage protection Resolved the issue of firmware version parsing error Resolved the issue where the device would fail to detect the short-circuit removal
V0.1.1	December 5, 2019	<ul style="list-style-type: none"> Added the short-circuit protection status and some warning status to the Modbus protocol Resolved the issue where the device would not be able to restore the default address after address allocation
V0.1.0	November 5, 2019	<ul style="list-style-type: none"> Added the functionality of switching parallel connected battery banks to shelf mode
V0.0.9	October 29, 2019	<ul style="list-style-type: none"> Improved the state of charge estimation algorithm Added the functionality of saving allocated device addresses
V0.0.7	August 22, 2019	<ul style="list-style-type: none"> Initial release